

USER MANUAL




EUROSPY **OBSERVER 003**

V/04/2017

INTRODUCTION

The Eurospy Observer 003 allows you to make recordings very discreetly as it is a camera integrated into a fake vehicle remote control. With the Observer 003 you can take pictures, make high resolution videos and also make voice recordings. In addition, it has infrared led that allow you to make short distance recordings in absolute darkness. The metal material which is built with makes the Observer 003 a very robust and lasting device.



Insert/remove the memory card

When opening the trapdoor 1 you will find the slot where the microSD memory card is located. We recommend that the memory card you use has to be of a recognized quality brand and always class 10. The maximum capacity of the card cannot exceed 32GB.

Charging the battery

When you open the trapdoor 2, you can access the USB connector. Connect the cable to the PC or an external USB charger (we recommend it be quality) about two hours. This should be done with the camera off.

Turn ON

Open the flap 2 to view the control LEDs. Now hold the button A until the blue and red led lights up and release. After two seconds the blue led will turn off automatically and the red led will remain on. At this time the camera is on in Standby mode but not recorded.

Video record (with sound)

In Standby mode (red led light on), click on the button "A" .The red led light will start blinking. The camera is now recording and you can now close the flap 2.

Stop video recording

While in recording mode (red LED blinking), click on "A" button. The red led stops blinking and stays steady on. The camera is now in Standby again.

Note: It is important when you are recording to first stop the video and then turn off the camera. If you turn off the camera without stopping the video, you will lose the last generated file.

Take photos

In Standby mode (red led light on), click on the "B" button. The red led changes to blue. The camera is now in photo mode instead of video mode. Now click the A button. The blue light turns off and on again, indicating that you have just taken a picture. Repeat as many times as necessary. To turn the camera off, press and hold the A button until the blue light turns off.

Make voice recording

The EuroSpy Observer 003 allows you to make voice recordings discreetly. While in Standby mode, click once and then click the B button again. The red and blue light will stay on indicating that the device is in voice recorder mode. Now click on the A button to start recording. The blue led remains steady and the red led is blinking.

When you want to stop the recording, click on button A. The red and blue led remain on. The recording has already been stopped successfully. If you want to turn off the device, press and hold button A until the LEDs turn off.

Note:

It is important when you want to finish making a recording, which you stop the recording first and then turn off the device. If you turn off the device without stopping recording, you will lose the last generated track.

Motion detection recording

The EuroSpy Observer 003 allows you to make video recordings (with sound) only when the camera detects movement. This will only work well in well-lit places and where the passage of a person is clear. Shadows and light changes can also trigger motion recording.

In Standby mode (red led light on), click button B three times leaving a margin of 3 seconds between click and click. The blue and red LEDs start blinking simultaneously. You now have the device in motion recording mode. To start the recording click on the button A. When you want to stop the recording, click again on the button A. To switch it off, press and hold button A until the lights go out.

Turn OFF

In Standby mode (red LED lit steady), hold down button "A" for two seconds until you see the blue light and release the button. The lights will go off.

View the videos in your computer

When the camera is off, connect the USB cable to your PC / notebook and a screen with the memory card directory opens. You will be able to view, copy, and delete any file as you normally would do with any other file in your PC.

Important:

Each time you press a button on the device, leave 3 seconds of margin before pressing again, so that the device can process the information.

The EuroSpy Observer 003 also incorporates a vibration system, so that, every time you press any function button, it will vibrate. So, with the practice, you no longer need to have to visualize the blue and red LED lights when you are giving orders to the device. You can just feel the vibrations and know what orders you are giving to the device.

For security reasons, when you make a video recording, the Observer 003 will automatically store 5-minute packet recordings. This means that if you perform for example a 30-minute recording, when you go to view the recordings on the computer, you will find 6 files of 5 minutes each

Set time/date

Connect the camera to the PC using the USB cable. Open Windows Notepad and type the following text:

AAAAMMDDHHMMSS Y

Where YYYY is the year, MM month, DD, date, HH hour, MM minute, SS seconds at the moment you are doing the setting, followed by a space and the letter Y.

Example: 20170425103000 Y. With this text we are telling the camera that we are on April 25, 2017 and it is 10:30. The letter Y is to tell the device to stamp the time / date in all the recordings.

This text has to be saved in the root directory of the memory card with the following file name:

TIMERSET.txt

Then disconnect the USB cable and make a video recording of few seconds so that the camera updates the date / time that we have just set.

Check the video and see that the time has properly set. If you have done everything well, when you make the first video, the TXT file will disappear from the root directory.

Features

Video format: .AVI

Video compression: M-JPEG

Video resolution: FullHD 1080P 1920x1080 30fps

Photo resolution: 12 Megapixels

Connection: USB 2.0

Battery work time: 1 hour

Charging time: 2-3 hours

Memory: max. 32GB

Max capacity of memory: N/A

Time and date: stamp in video.

Content

1 x Observer 003 camera

1 x Memory card 32GB microSD class 10

1 x USB cable

1 x User manual