

USER MANUAL



EUROSPY
AURAL 003

V/04/2017

INTRODUCTION

The Eurospy Aural 003 is a voice recorder with which you can make quality recordings very discreetly as it is integrated inside an external USB memory (Flash drive).

The built-in rechargeable lithium battery allows you to record up to 30 hours. It has an internal memory of 4GB that allows you to have stored up to 45 hours of recording.

The VOX system that incorporates makes it, once in recording mode, only record when it detects sound of more than 42 decibels.



Charging the battery

With the switch in the OFF position, connect the recorder directly to the USB port on your computer or to an external USB charger. It takes about 2 hours to fully charge the battery.

Recording by sound detection

Slide the switch to ON position. The red led will turn on for a few seconds, then blink and go off. Now you have started recording sound. The recorder has a VOX system that will only record when it detects sound of more than 40db. So if it does not detect sound, it will pause automatically until it detects sound again.

As you can see, the recorder does not emit any light when it is in recording mode, which makes it more discreet.

Recording while charging

The Aural003 Recorder allows you to make recordings while the battery is been charged, either connected to the USB port of your computer or to an external USB charger.

This allows you to record more hours (up to approx. 45 hours) by not having to rely on battery autonomy, since the only limitation would be the memory space.

In this mode, the recorder does not activate the motion recording system, but will continuously record until the internal memory card of the recorder is full.

To do this, turn the power switch to the ON position as if you were going to record as normal. When the red led is off and you are already recording, connect it to the USB port on your computer or external charger. The red led will not turn on and will remain off and the recorder will keep recording till the memory is full.

In case you have chosen to connect it to your PC, you will be able to check that no window is opened in the screen of your computer nor the directory of the memory card appears.

End recording

When you want to stop / turn off the recorder, turn the power switch to OFF. The red led light will light for a few seconds indicating that it is stopping the recording and will then turn off. Now it is completely off.

Listening the recordings

To listen the recordings, with the switch in OFF position, connect the recorder directly to the USB port of your computer. A window will appear on your computer with the folder where you have all the recordings (similar to when you connect an external Flash drive to your computer).

Erase stored recordings

From your PC / Laptop with the recorder connected through the USB port, you can erase / cut / move any voice file stored in the memory of your recorder like you would normally do with a common Flash drive.

Features

Record quality	192kbps
Recording format	WAV
Memory type	4Gb build-in
Memory autonomy	45h approx.
Battery	120mAh
Size in mm	40x12x5
Battery work time	About 30 hours
Charging time	2 - 3 hours
Connection	USB

Content

1 x Voice recorder AURAL 003
1 x User manual